

# Beverage Fountain Instructions

**IMPORTANT NOTE:** This fountain is designed to use clear beverages. **Do not use beverages with pulp, seeds, rinds, fruit, etc.** Items returned that have been used with beverages other than clear liquids will be charged an additional cleaning/maintenance fee and no refund will be offered for poor performance.

## **OPERATION**

1. Pour approximately ten quarts of beverage into the lower reservoir and switch on the fountain. If the beverage does not circulate within one minute, turn switch off, wait 10 seconds and turn back on. Repeat this procedure several times until beverage flows freely.
2. If this procedure fails, pour beverage in the top reservoir with the switch on until the pump is activated.

## **DO NOT DISMANTLE THE FOUNTAIN.**

If it is not working properly, please call us. We will do the cleaning.

### Helpful Hints

Chill your beverage to about 36F degrees before adding it to the fountain.

When using carbonated beverages, use smaller quantities and refill periodically to maintain carbonation. Carbonation will dissipate after 10 to 20 minutes of circulation.

If you experience with the fountain please call 360-754-7368 for assistance.

Thank you for including Celebrations in your event!